

# Technical Reference PMBus BMR320x000/001

This appendix contains a detailed reference of the PMBus commands supported by the product.

#### **Data Formats**

The products make use of a few standardized numerical formats, along with custom data formats. A detailed walkthrough of the above formats is provided in AN304, as well as in sections 7 and 8 of the PMBus Specification Part II. The custom data formats vary depending on the command and are detailed in the command description.

## **Standard Commands**

The functionality of commands with code 0x00 to 0xCF is usually based on the corresponding command specification provided in the PMBus Standard Specification Part II (see Power System Management Bus Protocol Documents below). However, there might be different interpretations of the PMBus Standard Specification or only parts of the Standard Specification applied, thus the detailed command description below should always be consulted.

#### **Forum Websites**

The System Management Interface Forum (SMIF)

http://www.powersig.org/

The System Management Interface Forum (SMIF) supports the rapid advancement of an efficient and compatible technology base that promotes power management and systems technology implementations. The SMIF provides a membership path for any company or individual to be active participants in any or all the various working groups established by the implementer forums.

Power Management Bus Implementers Forum (PMBUS-IF)

http://pmbus.org/

The PMBus-IF supports the advancement and early adoption of the PMBus protocol for power management. This website offers recent PMBus specification documents, PMBus articles, as well as upcoming PMBus presentations and seminars, PMBus Document Review Board (DRB) meeting notes, and other PMBus related news.

#### PMBus – Power System Management Bus Protocol Documents

These specification documents may be obtained from the PMBus-IF website described above. These are required reading for complete understanding of the PMBus implementation. This appendix will not re-address all of the details contained within the two PMBus Specification documents.

Specification Part I - General Requirements Transport and Electrical Interface

Includes the general requirements, defines the transport and electrical interface and timing requirements of hardwired signals.

Specification Part II - Command Language

Describes the operation of commands, data formats, fault management and defines the command language used with the PMBus.

#### SMBus – System Management Bus Documents

System Management Bus Specification, Version 2.0, August 3, 2000

This specification specifies the version of the SMBus on which Revision 1.2 of the PMBus Specification is based. This specification is freely available from the System Management Interface Forum Web site at: <a href="http://www.smbus.org/specs/">http://www.smbus.org/specs/</a>



# PMBus Command Summary and Factory Default Values of Standard Configuration

The factory default values provided in the table below are valid for the Standard configuration. Factory default values for other configurations can be found using the Flex Power Designer tool.

Code	Name	Data Format	Factory Default V	/alue
Joan	Tairio	Bata i Simat	Standard Configu	
			BMR320X000/00	
0x00	PAGE	R/W Byte	Bivii (020) (000)	
0x01	OPERATION	R/W Byte		
0x02	ON_OFF_CONFIG	R/W Byte	0x16	
0x03	CLEAR FAULTS	Send Byte	00	
0x10	WRITE_PROTECT	R/W Byte	0x00	
0x19	CAPABILITY	Read Byte	0x20	
0x10	VOUT_MODE	Read Byte	0x1B	
0x35	VIN_ON	R/W Word	0xE928	37.00 V
0x40	VOUT_OV_FAULT_LIMIT	R/W Word	0x00FB	7.84 V
0x40 0x41	VOUT_OV_FAULT_RESPONSE	R/W Byte	0x80	7.04 V
0x41 0x42	VOUT_OV_FAULT_RESPONSE  VOUT_OV_WARN_LIMIT	R/W Word	0x00F0	7.50 V
0x42 0x43	VOUT_UV_WARN_LIMIT	R/W Word	0x0090	4.50 V
0x44	VOUT_UV_FAULT_LIMIT	R/W Word	0x0080	4.00 V
0x45	VOUT_UV_FAULT_RESPONSE	R/W Byte	0x80	00.00.4
0x46	IOUT_OC_FAULT_LIMIT	R/W Word	0xF168	90.00 A
0x47	IOUT_OC_FAULT_RESPONSE	R/W Byte	0xC0	
0x4A	IOUT_OC_WARN_LIMIT	R/W Word	0xF154	85.00 A
0x4F	OT_FAULT_LIMIT	R/W Word	0x007D	125.00 °C
0x50	OT_FAULT_RESPONSE	R/W Byte	0x80	
0x51	OT_WARN_LIMIT	R/W Word	0x0073	115.00 °C
0x55	VIN_OV_FAULT_LIMIT	R/W Word	0xEA00	64.00 V
0x56	VIN_OV_FAULT_RESPONSE	R/W Byte	0x80	
0x59	VIN_UV_FAULT_LIMIT	R/W Word	0xE91C	35.50 V
0x5A	VIN_UV_FAULT_RESPONSE	R/W Byte	0x80	
0x78	STATUS_BYTE	Read Byte		
0x79	STATUS_WORD	Read Word		
0x7A	STATUS_VOUT	Read Byte		
0x7B	STATUS_IOUT	Read Byte		
0x7C	STATUS_INPUT	Read Byte		
0x7D	STATUS_TEMPERATURE	Read Byte		
0x7E	STATUS CML	Read Byte		
0x80	STATUS_MFR_SPECIFIC	Read Byte		
0x88	READ_VIN	Read Word		
0x8B	READ_VOUT	Read Word		
0x8C	READ_IOUT	Read Word		
0x8D	READ_TEMPERATURE_1	Read Word		
0x98	PMBUS REVISION	Read Byte	0x33	
0x99	MFR ID	Read Block2	0x001A	
0x9A	MFR MODEL	Read Block2	0x6000	
0x9B	MFR REVISION	Read Block2	0x0000	
0x9D	MFR_DATE	Read Block2	Unit Specific	
0xB0	MFR_SPEC_SERIAL	Read Block4	Unit Specific	
0xB0	MFR SPEC MODEL REV	Read Block8	Unit Specific	
0xC4	PASSW_I2C	Write Word	Offic Opecific	
0xC4 0xC5	PASSW_0TP	Write Word		
0xC6	PASSW_OTP PASSW_ADDR	Write Word		
0xC6				
	OTP_WRITE DEVICE_FULL_ADDRESS	Read Byte		
0xD3		Read Byte	0,00	
0xD4	DCX_VOUT_SS_FAULT	R/W Byte	0x08	
0xD6	OTP_UPLOAD	R/W Byte		



0xD8	NTC_CS_LUT_STATUS	Read Byte	0x03
0xDF	DCX_SS_PROTECTION	R/W Byte	0x15
0xE0	PMBUS_BASE_ADDRESS	R/W Byte	0x44
0xE1	NTC_LUT_CRC16_READ	Read Word	
0xE2	CS_LUT_CRC16_READ	Read Word	
0xEE	CHECKSUM_CRC	Read Word	Unit Specific
0xF0	REG_CON_OFFSET_IOUT	R/W Byte	Unit Specific
0xF1	REG_CON_MULT_IOUT	R/W Byte	Unit Specific



#### **PMBus Command Details**

#### PAGE (0x00)

Description: Page command

Bit	Description	Format
7:0	Command for compatibility only, no function. Valid values are 0x00 and 0xFF.	Integer Unsigned

## **OPERATION (0x01)**

Description: Sets the desired PMBus enable operation.

Bit	Description	Value	Function	Description
7:6	Make the device enable or disable if PMBus Enable has been activated in ON_OFF_CONFIG.	00	Immediate Off	Disable Immediately without sequencing.
		10	Enable	Enable device to the set voltage.

#### ON\_OFF\_CONFIG (0x02)

Description: Configures how the device is controlled by the EN pin and the PMBus OPERATION command. When entering PMBus enable mode (bit 3 changed from 0 to 1), OPERATION command changes to 0x00 and the output is turned off, if enabled. Thus, it is recommended that the output voltage is disabled when changing bit 3. If both bit 2 and bit 3 are set (enable by pin + by PMBus command) the enable pin must be active to allow control by OPERATION command. However, the enable pin can always control the output voltage regardless of the value of OPERATION command.

Bit	Function	Description	Value	Function	Description
4	Powerup Operation	Must be set to 1.	1	Enable pin or PMBus	Unit does not power up until commanded by the CONTROL pin and OPERATION command.
3	PMBus Enable Mode	Controls how the unit responds to commands received via the serial bus.	0	Ignore PMBus	Unit ignores the on/off portion of the OPERATION command from serial bus.
			1	Use PMBus	To start, the unit requires that the on/off portion of the OPERATION command is instructing the unit to run.
2	Enable Pin Mode	Controls how the unit responds to the CONTROL pin.	0	Ignore pin	Unit ignores the CONTROL/Enable pin.
			1	Use pin	Unit requires the CONTROL pin to be asserted to start the unit.
1	Enable Pin Polarity	Polarity of the CONTROL pin.	1	Active High	Enable pin will cause device to enable when driven high.
	-		0	Active Low	Enable pin will cause device to enable when driven low.
0	Disable Action	Must be set to 1.	1	Imm. Off	Turn off the output and stop transferring energy to the output as fast as possible.



## CLEAR\_FAULTS (0x03)

Description: Clears all fault status bits

#### WRITE PROTECT (0x10)

Description: The WRITE\_PROTECT command is used to control writing to the PMBus device. The intent of this command is to provide protection against accidental changes. This command is not intended to provide protection against deliberate or malicious changes to a device's configuration or operation. Above what is specified in the PMBus standard the following protection modes are available: Data 0000 0011 => Disable all writes

Bit	Description	Value	Function	Description
7:0	All supported commands may have their parameters read, regardless of the WRITE_PROTECT settings.	0x80	Enable write command	Disable all writes except to the WRITE_PROTECT command.
		0x40	Enable operation	Disable all writes except to the WRITE_PROTECT, OPERATION and PAGE commands.
		0x20	Enable control and Vout commands	Disable all writes except to the WRITE_PROTECT, OPERATION, PAGE, ON_OFF_CONFIG and VOUT_COMMAND commands.
		0x03	Disable all writes	Disable all writes. Deadlock - needs a recycle of input voltage to unlock.
		0x02	Enable Vout command	Disable all writes except to the VOUT_COMMAND command. Deadlock - needs a recycle of input voltage to unlock.
		0x00	Enable all commands	Enable writes to all commands.

#### CAPABILITY (0x19)

Description: This command provides a way for a host system to determine some key capabilities of a PMBus device.

Bit	Function	Description	Value	Function	Description
7	Packet Error Checking	Packet error checking.	00	Not Supported	Packet Error Checking not supported.
			01	Supported	Packet Error Checking is supported.
6:5	Maximum Bus Speed	Maximum bus speed.	00	100kHz	Maximum supported bus speed is 100 kHz.
			01	400kHz	Maximum supported bus speed is 400 kHz.
			10	1MHz	Maximum supported bus speed is 1 MHz.
4	Smbalert	SMBALERT	00	No Smbalert	The device does not have a SMBALERT# pin and does not support the SMBus Alert Response protocol.
			01	Have Smbalert	The device does have a SMBALERT# pin and does support the SMBus Alert Response protocol.
3	Numeric Format	Numeric format.	0	LINEAR or DIRECT Format	Numeric data is in LINEAR or DIRECT format.



			1	IEEE Half	Numeric data is in IEEE half
				Precision	precision floating point format.
				Floating Point	
				Format	
2	AVSBus	AVSBus support.	0	AVSBus Not	AVSBus not supported.
	Support			Supported	
			1	AVSBus	AVSBus supported.
				Supported	

## VOUT\_MODE (0x20)

Description: Controls how future VOUT-related commands parameters will be interpreted.

Bit	Function	Description	Format
4:0		Five bit two's complement EXPONENT for the MANTISSA delivered as the	Integer Signed
		data bytes for VOUT_COMMAND in VOUT_LINEAR Mode, five bit VID	
		code identifier per in VID Mode or always set to 00000b in Direct Mode.	

Bit	Function	Description	Value	Function	Description
7:5		Set to 000b to select	000	Linear	Linear Mode Format.
		VOUT_LINEAR Mode (Five bit	001	VID	VID Mode.
		two's complement exponent for the MANTISSA delivered as the data bytes for an output voltage related command), set to 001b to select VID Mode (Five bit VID code identifier per) or set to 010b to select Direct Mode (Always set to 00000b).	010	Direct	Direct Mode.

## VIN\_ON (0x35)

Description: The VIN\_ON command sets the value of the input voltage, in volts, at which the unit should start power conversion.

Bit	Description	Format	Unit
15:0	Sets the VIN ON threshold. Linear exponent must be set to -3.	Linear	V

## VOUT\_OV\_FAULT\_LIMIT (0x40)

Description: Output over voltage fault limit.

Bit	Description	Format	Unit
15:0	Output over voltage fault limit.	Vout Mode	V
		Unsigned	
		(Exp = -5)	

#### VOUT\_OV\_FAULT\_RESPONSE (0x41)

Description: Output over voltage fault response.

Bit	Function	Description	Format	Unit
2:0	Retry Time	Delay time in 200 ms units between attempts to restart.	Fixed Point	ms
	and Delay		Unsigned	
	Time			

Bit	Function	Description	Value	Function	Description
7:6	Response		00	Ignore Fault	The PMBus device continues
					operation without interruption.



		Describes the device interruption operation. 00b - The PMBus device continues operation without interruption. 10b - The device shuts down (disables the output) and responds according to the Retry Setting in bits [5:3].	10	Disable and retry	The device shuts down (disables the output) and responds according to the retry setting in bits [5:3].
5:3	Retries	The device attempts to restart the number of times set by these bits. 000b means the device does not attempt a restart. 111b means the device attempts restarting	000	Do Not Retry	A zero value for the Retry Setting means that the unit does not attempt to restart. The output remains disabled until the fault is cleared (Section 10.7).
		continuously.	001	Retry Once	The PMBus device attempts to restart 1 time. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			010	Retry Twice	The PMBus device attempts to restart 2 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			011	Retry 3 times	The PMBus device attempts to restart 3 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			100	Retry 4 times	The PMBus device attempts to restart 4 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.



101	Retry 5 times	The PMBus device attempts to restart 5 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
110	Retry 6 times	The PMBus device attempts to restart 6 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
111	Retry Continuously	The PMBus device attempts to restart continuously, without limitation, until it is commanded OFF (by the CONTROL pin or OPERATION command or both), bias power is removed, or another fault condition causes the unit to shut down.

**VOUT\_OV\_WARN\_LIMIT (0x42)**Description: Output over voltage warning limit.

Bit	Description	Format	Unit
15:0	Output over voltage warning limit.	Vout Mode	V
		Unsigned	
		(Exp = -5)	



# VOUT\_UV\_WARN\_LIMIT (0x43)

Description: Output under voltage warning limit.

Bit	Description	Format	Unit
15:0	Output under voltage warning limit.	Vout Mode	V
		Unsigned	
		(Exp = -5)	

## VOUT\_UV\_FAULT\_LIMIT (0x44)

Description: Output under voltage fault limit.

Bit	Description	Format	Unit
15:0	Output under voltage fault limit.	Vout Mode	V
		Unsigned	
		(Exp = -5)	

# VOUT\_UV\_FAULT\_RESPONSE (0x45)

Description: Output under voltage fault response.

Bit	Function	Description	Format	Unit
2:0	Retry Time	Delay time in 200 ms units between attempts to restart.	Fixed Point	ms
	and Delay		Unsigned	
	Time			

Bit	Function	Description	Value	Function	Description
7:6	Response	Describes the device interruption operation. 00b - The PMBus	00	Ignore Fault	The PMBus device continues operation without interruption.
		device continues operation without interruption. 10b - The device shuts down (disables the output) and responds according to the Retry Setting in bits [5:3].	10	Disable and retry	The device shuts down (disables the output) and responds according to the retry setting in bits [5:3].
5:3	Retries	The device attempts to restart the number of times set by these bits. 000b means the device does not attempt a restart. 111b means the device attempts restarting	000	Do Not Retry	A zero value for the Retry Setting means that the unit does not attempt to restart. The output remains disabled until the fault is cleared (Section 10.7).
		continuously.	001	Retry Once	The PMBus device attempts to restart 1 time. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			010	Retry Twice	The PMBus device attempts to restart 2 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.



1	044	D = 4m + O +1	The DMD and a device of the sector of
	011	Retry 3 times	The PMBus device attempts to restart 3 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	100	Retry 4 times	The PMBus device attempts to restart 4 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	101	Retry 5 times	The PMBus device attempts to restart 5 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	110	Retry 6 times	The PMBus device attempts to restart 6 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	111	Retry Continuously	The PMBus device attempts to restart continuously, without limitation, until it is commanded OFF (by the CONTROL pin or OPERATION command or both), bias power is removed, or another fault condition causes the unit to shut down.

# IOUT\_OC\_FAULT\_LIMIT (0x46)

Description: Output over current limit.

Bit	Description	Format	Unit
15:	Output over current fault limit. Linear exponent must be -2.	Linear	Α

# IOUT\_OC\_FAULT\_RESPONSE (0x47)

Description: Output over current fault response.

Bit	Function	Description	Format	Unit



Ī	2:0	Retry Time	Delay time in 200 ms units between attempts to restart.	Fixed Point	ms
		and Delay		Unsigned	
		Time		_	

Bit	Function	Description	Value	Function	Description
7:6	Response	For all values of bits [7:6],the device: Sets the corresponding fault bit in the status registers and If the device supports notifying the host, it does so.	11	Ignore Fault  Disable and	The PMBus device continues to operate indefinitely while maintaining the output current at the value set by IOUT_OC_FAULT_LIMIT without regard to the output voltage (known as constant-current or brickwall limiting).
				Retry	The device shuts down (disables the output) and responds according to the retry setting in bits [5:3].
5:3	Retries	The device attempts to restart the number of times set by these bits. 000b means the device does not attempt a restart. 111b means the device attempts restarting	000	Do Not Retry	A zero value for the Retry Setting means that the unit does not attempt to restart. The output remains disabled until the fault is cleared (Section 10.7).
		continuously.	001	Retry Once	The PMBus device attempts to restart 1 time. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			010	Retry Twice	The PMBus device attempts to restart 2 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			011	Retry 3 times	The PMBus device attempts to restart 3 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.



	100	Retry 4 times	The PMBus device attempts to restart 4 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	101	Retry 5 times	The PMBus device attempts to restart 5 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	110	Retry 6 times	The PMBus device attempts to restart 6 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	111	Retry Continuously	The PMBus device attempts to restart continuously, without limitation, until it is commanded OFF (by the CONTROL pin or OPERATION command or both), bias power is removed, or another fault condition causes the unit to shut down.

# IOUT\_OC\_WARN\_LIMIT (0x4A)

Description: Output over current warning limit.

Bit	Description	Format	Unit
15:0	Output over current warning limit. Linear exponent must be set to -2.	Linear	Α

# OT\_FAULT\_LIMIT (0x4F)

Description: Over temperature fault limit.

Е	3it	Description	Format	Unit
	15:0	Over temperature fault limit. Linear exponent must be set to 0.	Linear	°C

## OT\_FAULT\_RESPONSE (0x50)

Description: Over temperature fault response.

Bit	Function	Description	Format	Unit
2:0	Retry Time and Delay	Delay time in 200 ms units between attempts to restart.	Fixed Point Unsigned	ms
	Time		3 - 1	



Bit	Function	Description	Value	Function	Description
7:6	Response		00	Ignore Fault	The PMBus device continues
			10	Disable and retry	operation without interruption.  The device shuts down (disables the output) and responds according to the retry setting in
5:3	Retries		000	Do Not Retry	bits [5:3].  A zero value for the Retry Setting means that the unit does not attempt to restart. The output remains disabled until the fault is cleared (Section 10.7).
			001	Retry Once	The PMBus device attempts to restart 1 time. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			010	Retry Twice	The PMBus device attempts to restart 2 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			011	Retry 3 times	The PMBus device attempts to restart 3 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			100	Retry 4 times	The PMBus device attempts to restart 4 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.



101	Retry 5 times	The PMBus device attempts to restart 5 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
110	Retry 6 times	The PMBus device attempts to restart 6 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
111	Retry Continuously	The PMBus device attempts to restart continuously, without limitation, until it is commanded OFF (by the CONTROL pin or OPERATION command or both), bias power is removed, or another fault condition causes the unit to shut down.

OT\_WARN\_LIMIT (0x51)
Description: Over temperature warning limit.

	Bit	Description	Format	Unit
ĺ	15:0	Over temperature warning limit. Linear exponent must be set to 0.	Linear	°C



# VIN\_OV\_FAULT\_LIMIT (0x55)

Description: Input over voltage fault limit.

Bit	Description	Format	Unit
15:0	Input over voltage fault limit. Linear exponent must be set to -3.	Linear	V

# VIN\_OV\_FAULT\_RESPONSE (0x56)

Description: Input over voltage fault response.

Bit	Function	Description	Format	Unit
2:0	Retry Time and Delay Time	Delay time in 200 ms units between attempts to restart.	Fixed Point Unsigned	ms

Bit	Function	Description	Value	Function	Description
7:6	Response		00	Ignore Fault	The PMBus device continues operation without interruption.
			10	Disable and retry	The device shuts down (disables the output) and responds according to the retry setting in bits [5:3].
5:3	Retries	tries	000	Do Not Retry	A zero value for the Retry Setting means that the unit does not attempt to restart. The output remains disabled until the fault is cleared (Section 10.7).
			001	Retry Once	The PMBus device attempts to restart 1 time. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			010	Retry Twice	The PMBus device attempts to restart 2 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			011	Retry 3 times	The PMBus device attempts to restart 3 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.



	100	Retry 4 times	The PMBus device attempts to restart 4 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	101	Retry 5 times	The PMBus device attempts to restart 5 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	110	Retry 6 times	The PMBus device attempts to restart 6 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	111	Retry Continuously	The PMBus device attempts to restart continuously, without limitation, until it is commanded OFF (by the CONTROL pin or OPERATION command or both), bias power is removed, or another fault condition causes the unit to shut down.

# VIN\_UV\_FAULT\_LIMIT (0x59)

Description: Input under voltage fault limit.

Bit	Description	Format	Unit
15:0	Input under voltage fault limit. Linear exponent must be set to -3.	Linear	V

# VIN\_UV\_FAULT\_RESPONSE (0x5A)

Description: Input under voltage fault response.

	Bit	Function	Description	Format	Unit
Ī	2:0	Retry Time	Delay time in 200 ms units between attempts to restart.	Fixed Point	ms
		and Delay		Unsigned	
		Time		_	

Bit	Function	Description	Value	Function	Description
7:6	Response		00	Ignore Fault	The PMBus device continues
					operation without interruption.



			10	Disable and	The device shuts down (disables
				retry	the output) and responds according to the retry setting in bits [5:3].
5:3	Retries		000	Do Not Retry	A zero value for the Retry Setting means that the unit does not attempt to restart. The output remains disabled until the fault is cleared (Section 10.7).
			001	Retry Once	The PMBus device attempts to restart 1 time. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
			010	Retry Twice	The PMBus device attempts to restart 2 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
		011	Retry 3 times	The PMBus device attempts to restart 3 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.	
			100	Retry 4 times	The PMBus device attempts to restart 4 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.



	101	Retry 5 times	The PMBus device attempts to restart 5 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	110	Retry 6 times	The PMBus device attempts to restart 6 times. If the device fails to restart, it disables the output and remains off until the fault is cleared as described in Section 10.7. The time between the start of each attempt to restart is set by the value in bits [2:] along with the delay time unit specified for that particular fault.
	111	Retry Continuously	The PMBus device attempts to restart continuously, without limitation, until it is commanded OFF (by the CONTROL pin or OPERATION command or both), bias power is removed, or another fault condition causes the unit to shut down.

# STATUS\_BYTE (0x78)

Description: Returns a brief fault/warning status byte.

Bit	Function	Description	Value	Description
6			0	No fault
		to the output, regardless of the reason, including	1	Fault
		simply not being enabled.		
5	Vout Overvoltage	An output overvoltage fault has occurred.	0	No fault
	Fault		1	Fault
4	lout Overcurrent Fault	An output overcurrent fault has occurred.	0	No fault
			1	Fault
3	Vin Undervoltage	An input undervoltage fault has occurred.	0	No fault
	Fault		1	Fault
2	Temperature	A temperature fault or warning has occurred.	0	No fault
			1	Fault
1	Communication/Logic	A communications, memory or logic fault has	0	No fault
		occurred.	1	Fault
0	None of the Above	A fault or warning not listed in bits [7:1] has	0	No fault
		occurred.	1	Fault



**STATUS\_WORD (0x79)**Description: Returns an extended fault/warning status byte.

Bit	Function	Description	Value	Description
15	Vout	An output voltage fault or warning has occurred.	0	No fault
			1	Fault
14	lout/Pout	An output current or output power fault or warning	0	No Fault.
		has occurred.		Fault.
13	Input	An input voltage, input current, or input power fault	0	No Fault.
		or warning has occurred.		Fault.
12	Mfr Specific	A manufacturer specific fault or warning has	0	No Fault.
		occurred.	1	Fault.
11	Power-Good	The Power-Good signal, if present, is negated.	0	No Fault.
			1	Fault.
6	Off	This bit is asserted if the unit is not providing power	0	No fault
		to the output, regardless of the reason, including	1	Fault
		simply not being enabled.		
5	Vout Overvoltage	An output overvoltage fault has occurred.	0	No Fault.
	Fault		1	Fault.
4	Iout Overcurrent Fault	An output overcurrent fault has occurred.	0	No Fault.
			1	Fault.
3	Vin Undervoltage	An input undervoltage fault has occurred.	0	No Fault.
	Fault		1	Fault.
2	Temperature	A temperature fault or warning has occurred.	0	No Fault.
			1	Fault.
1	Communication/Logic	A communications, memory or logic fault has	0	No fault.
		occurred.	1	Fault.
0	None of the Above	A fault or warning not listed in bits [7:1] has	0	No fault.
		occurred.	1	Fault.



## STATUS\_VOUT (0x7A)

Description: Returns Vout-related fault/warning status bits.

Bit	Function	Description	Value	Description
7	Vout Overvoltage	Vout Overvoltage Fault.	0	No Fault.
	Fault		1	Fault.
6	Vout Overvoltage	Vout Overvoltage Warning.	0	No Warning.
	Warning		1	Warning.
5	Vout Undervoltage	Vout Undervoltage Warning.	0	No Warning.
	Warning		1	Warning.
4	Vout Undervoltage	Vout Undervoltage Fault.	0	No Fault.
	Fault	-	1	Fault.

## STATUS\_IOUT (0x7B)

Description: Returns lout-related fault/warning status bits.

Bit	Function	Description	Value	Description
7	lout Overcurrent Fault	lout Overcurrent Fault.	0	No Fault.
			1	Fault.
5	Iout Over Current	Iout Overcurrent Warning.	0	No Warning.
	Warning		1	Warning.
1	Pout Over Power	Pout Over Power Fault.	0	No Fault.
	Fault		1	Fault.
0	Pout Over Power	Pout Over Power Warning.	0	No Warning.
	Warning		1	Warning.

## STATUS\_INPUT (0x7C)

Description: Returns VIN/IIN-related fault/warning status bits.

Bit	Function	Description	Value	Description
7	Vin Overvoltage Fault	Vin Overvoltage Fault.	0	No Fault.
			1	Fault.
6	Vin Overvoltage	VIN Overvoltage Warning.	0	No Warning.
	Warning		1	Warning.
5	Vin Undervoltage	Vin Undervoltage Warning.	0	No Warning.
	Warning		1	Warning.
4	Vin Undervoltage	Vin Undervoltage Fault.	0	No Fault.
	Fault		1	Fault.
3	Insufficient Vin	Asserted when either the input voltage has never	0	No Insufficient VIN
		exceeded the input turn-on threshold Vin-On, or if		encountered yet.
		the unit did start, the input voltage decreased below	1	Insufficient Unit is off.
		the turn-off threshold.		

## STATUS\_TEMPERATURE (0x7D)

Description: Returns the temperature-related fault/warning status bits

Bit	Function	Description	Value	Description
7	Overtemperature	Overtemperature Fault.	0	No Fault.
	Fault		1	Fault.
6	Overtemperature	Overtemperature Warning.	0	No Warning.
	Warning	,	1	Warning.



# STATUS\_CML (0x7E)

Description: Returns Communication/Logic/Memory-related fault/warning status bits.

Bit	Function	Description	Value	Description
7	Invalid or	Invalid or Unsupported Command Received.	0	No Invalid Command
	Unsupported			Received.
	Command Received		1	Invalid Command
				Received.
6	Invalid or	Invalid or Unsupported Data Received.	0	No Invalid Data
	Unsupported Data			Received.
	Received		1	Invalid Data Received.
5	Packet Error Check	Packet Error Check Failed.	0	No Failure.
	Failed		1	Failure.
4	Memory Fault	Memory Fault Detected.	0	No Fault.
	Detected		1	Fault.

## STATUS\_MFR\_SPECIFIC (0x80)

Description: Returns manufacturer specific status information.

Bit	Function	Description	Value	Description
7	Analog Ratio	Analog Ratio Protection.	0	No Fault.
	Protection		1	Fault.
6	Digital Ratio	Digital Ratio Protection; N * Vout - VINSS.	0	No Fault.
	Protection		1	Fault.
5	Buck Duty Fault	Buck duty fault;  VBUS - VINSS  < K * VINSS.	0	No Fault.
			1	Fault.
4	Analog (peak) OC	Analog (peak) OC protection.	0	No Fault.
	Protection		1	Fault.
2	Vout Monotonic Rise	Vout rise is not monotonic at startup, i.e. short	0	No Fault.
	Fault	circuit on output.	1	Fault.
1	VCC Boot Below	At the start-up, the VCC was below threshold.	0	No Fault.
	Threshold	·	1	Fault.
0	Vout Boot Below	At the start-up, the VOUT was below threshold.	0	No Fault.
	Threshold		1	Fault.

# READ\_VIN (0x88)

Description: Returns the measured input voltage.

Bit	Description	Format	Unit
15:0	Returns the input voltage reading.	Linear	V

## READ\_VOUT (0x8B)

Description: Returns the measured output voltage.

Bit		Description	Format	Unit
15:	:0	Returns the measured output voltage.	Vout Mode	V
			Unsigned	
			(Exp = -5)	



## READ\_IOUT (0x8C)

Description: Returns the measured output current.

Bit	Description	Format	Unit
15:0	The device will NACK this command when not enabled and not in the USER_CONFIG	Linear	Α
	monitor mode.		

#### READ\_TEMPERATURE\_1 (0x8D)

Description: Reads temperature from the temperature sensor chosen in MFR\_SELECT\_TEMPERATURE\_SENSOR (0xDC) command.

Bit	Description	Format	Unit
15:0		Linear	°C

#### PMBUS\_REVISION (0x98)

Description: Returns the PMBus revision number for this device.

Bit	Function	Description	Value	Function	Description
7:4	Part I Revision	Part I Revision.	0x0	1.0	Part I Revision 1.0.
			0x1	1.1	Part I Revision 1.1.
			0x2	1.2	Part I Revision 1.2.
			0x3	1.3	Part I Revision 1.3.
3:0	Part II	Part II Revision.	0x0	1.0	Part II Revision 1.0.
	Revision		0x1	1.1	Part II Revision 1.1.
			0x2	1.2	Part II Revision 1.2.
			0x3	1.3	Part II Revision 1.3.

#### MFR\_ID (0x99)

Description: Sets the Manufacturers ID

	Bit	Description	Format
ſ	15:0	Manufacturer ID.	Integer Unsigned

## MFR\_MODEL (0x9A)

Description: Mfr. Model

Bit	Description	Format
15:0	Mfr Model	ASCII

#### MFR\_REVISION (0x9B)

Description: Sets the MFR revision string.

Bit	Description	Format
15:0	Mfr. Revision.	Integer Unsigned

# MFR\_DATE (0x9D)

Description: This command returns the date the regulator was manufactured.

Bit	Function	Description	Format
15:8	Mfr. Week	The week number.	Integer Unsigned
7:0	Mfr. Year	The year (e.g. 20 stands for 2020).	Integer Unsigned



# MFR\_SPEC\_SERIAL (0xB0)

Description: Contains serial # from production.

Bit	Function	Description	Format
31:27	Test station	Test station number, e.g. 00000 = X01	Integer Unsigned
	number		
26:0	Serial number	Serial number. Decimal number calculated as: 100000 x (Last three digits	Integer Unsigned
		of production order number) + counter number	-

# MFR\_SPEC\_MODEL\_REV (0xB1)

Description: Contains product number and revision information.

Bit	Function	Description	Format
63	Scheme ID	Always 1	Integer Unsigned
59:50	BMR number	Number 0-999.	Integer Unsigned
	3-digit		
49:46	BMR number	Number 0-9.	Integer Unsigned
	1-digit		
45:42	BMR number	Number 0-9.	Integer Unsigned
	1-digit		
41:38	BMR number	Number 0-9.	Integer Unsigned
	1-digit		
37:34	BMR number	Number 0-9.	Integer Unsigned
	1-digit		
33:24	BMR number	Number 0-999.	Integer Unsigned
	after /		
22:17	Product	Number 1-63.	Integer Unsigned
	revision		
	number		
16:12	Product	Number 1-26 represents A-Z.	Integer Unsigned
	revision letter	·	
10:6	Config revision	Number 1-26 represents A-Z.	Integer Unsigned
	letter	•	
5:0	Config revision	Number 1-63. Ignore for sharp release.	Integer Unsigned
	number	-	

Bit	Function	Description	Value	Description
23	Product preliminary	0=Sharp revision (e.g. R1A), 1=Preliminary revision	0	Sharp revision (e.g. R1A)
	revision	(e.g. P1A)	1	Preliminary revision (e.g. P1A)
11	Config preliminary	0=Sharp revision, 1=Preliminary revision	0	Sharp revision
	revision		1	Preliminary revision

# PASSW\_I2C (0xC4)

Description: Password for I2C

I	Bit	Description	Format
Ī	15:0	Write value 0xC93F to this command to enable I2C register writes. Writing the password to	Byte Array
		this command is also required for passwords in 0xC5 and 0xC6 to be effective.	



## PASSW\_OTP (0xC5)

Description: Password for OTP

Bit	Description	Format
15:0	Write value 0x4B6A to this command to enable the burn OTP function (0xD6 command). It is	Byte Array
	also required that the password is written to command 0xC4.	

## PASSW\_ADDR (0xC6)

Description: Password for ADDRESS

Bit	Description	Format
15:0	Write value 0xF1C0 to this command to enable the custom PMBUS base address setting	Byte Array
	(0xE0 command). It is also required that the password is written to command 0xC4.	

#### OTP\_WRITE (0xCF)

Description: Available # of OTP write cycles

Bit	Description	Format
7:0	Returns how many OTP writes that are left. Use before a 0xD6 command write.	Integer Unsigned

# DEVICE\_FULL\_ADDRESS (0xD3)

Description: Reads PMBus address 8 bit

Bit	Description	Format
7:0	Returns the PMBus device address aligned on 8 bit.	Byte Array

## DCX\_VOUT\_SS\_FAULT (0xD4)

Description: Soft start rise check step size

Bit	Description	Format
7:0	Enable/disable and specify the incremental step of the monotonic check in Vout mantissa	Integer Unsigned
	number. The value is Vout_step (value of Vout PMBUS mantissa) where	
	Vout(n+1)>Vout(n)+Vout_step for a regular soft start. The sampling (n+1) and (n) are defined	
	by the command 0xDF. A value of 0 means monotonic check is disabled. The check is also	
	always disabled when Vout > 0.5 VOUT_UV_FAULT_LIMIT.	

#### OTP\_UPLOAD (0xD6)

Description: Store to OTP command

Bit	Description	Format
7:0	In Write mode, it saves the config values from RAM into OTP memory. Use payload 0xAA.	Byte Array
	PMBus commands are not accepted, wait 120 ms for the writing time. Before command is written, passwords must be written to 0xC4 and 0xC5. In Read mode, it returns 0xCC = written successfully; 0xFF = it's an error.	

# NTC\_CS\_LUT\_STATUS (0xD8)

Description: LUT memory area status

Bit	Description	Value	Function	Description
7:0	Returns the status of the LUT memory area: If 0x01,	0x00	No LUT stored	No LUT stored.
	LUT NTC stored If 0x02, LUT CS stored If 0x03,	0x01	NTC LUT	NTC LUT stored.
	LUT NTC and CS stored		stored	
		0x02	CS Gain LUT	CS Gain LUT stored.
			stored	
		0x03	NTC and CS	NTC and CS Gain LUTs stored.
			Gain LUTs	
			stored	



#### DCX\_SS\_PROTECTION (0xDF)

Description: Defines the sampling instants (n+1) and (n) for the command 0xD4.

Bit	Function	Description	Format	Unit
5:3	Initial sample	From 0.5 ms [000] to 2.25 ms [111], step 0.25 ms.	Fixed Point	ms
	time		Unsigned	

Bit	Function	Description	Value	Function	Description
2:0	Pace of	From 0.75 ms [011] to 1.75 ms	011	0.75 ms	
	samples (n)	[111], step 0.25 ms.	100	1.00 ms	
	and (n+1)		101	1.25 ms	
			110	1.50 ms	
			111	1.75 ms	

#### PMBUS\_BASE\_ADDRESS (0xE0)

Description: Sets the PMBUS base address of the address range. If a store failed and with blank part a default base address set equal to 0x1 (16d). Before command is written, passwords must be written to 0xC4 and 0xC6. After write, input voltage must be cycled before the base address is actually changed.

Bit	Description	Format
7:5	Base Address to start from. 000b => base address 0x00, 001b => base address 0x10, 010b	Fixed Point
	=> base address 0x20, 011b => base address 0x30, etc.	Unsigned

## NTC\_LUT\_CRC16\_READ (0xE1)

Description: Reads the checksum value for the NTC LUT.

Bit	Description	Format
15:0	NTC LUT CRC16 value.	Integer Unsigned

#### CS\_LUT\_CRC16\_READ (0xE2)

Description: Reads the checksum value for the CS Gain LUT.

Bit	Description	Format
15:0	CS Gain LUT CRC16 value.	Integer Unsigned

#### CHECKSUM\_CRC (0xEE)

Description: Calculated config file CRC

Bit	Description	Format
15:0	Returns the CRC16 calculated based on the configuration file. At POR and after STORE, the	Direct
	embedded processor compares the CRC16 signature placed in the configuration file with the	
	calculated CRC16. If they don't match, IC enters Recovery mode (no configuration file),	
	triggers the Memory Fault in STATUS_CML and set the PMBUS address to 0xB0.	



# REG\_CON\_OFFSET\_IOUT (0xF0)

Description: READ\_IOUT calibration offset

Bit	Function	Description	Format	Unit
6:0	READ_IOUT	Setting the offset to the READ_IOUT mantissa: Bit 7 = 0 for positive values	Fixed Point	Α
	calibration	and 1 for negative Bit 6:0 = offset of the PMBUS mantissa	Unsigned	
	offset value			

Bit	Function	Description	Value	Function	Description
7	READ_IOUT	Setting the offset to the	0	Positive offset	Positive offset.
	calibration offset sign bit	READ_IOUT mantissa: Bit 7 = 0 for positive values and 1 for negative Bit 6:0 = offset of the PMBUS mantissa	1	Negative offset	Negative offset.

# REG\_CON\_MULT\_IOUT (0xF1)

Description: READ\_IOUT calibration gain

Bit	Description	Format
7:0	Setting the internal gain of the READ_IOUT value.	Fixed Point
		Unsigned