



DESCRIPTION
THERMAL MODEL FOR
BMR492 0300/864
BMR492 2300/001



Contents

General.....	2
Model Description.....	2
3D CAD Geometry.....	2
Domains of power loss distribution.....	3
Domains of material data.....	3
Monitor points.....	4
Model Calibration.....	4
Model Usage.....	5
Additional Information.....	5
Reference.....	5
Disclaimer.....	5
Revision history.....	5
Appendix 1 - Power Loss Distribution.....	6

General

The model is an estimation for the thermal behavior of BMR492 0300/864 and BMR492 2300/001, which are through-hole pin design. The model is intended for steady-state thermal simulations.

Model Description

The model is a readymade Flotherm 11.1 model. It was created by importing a CAD model in STEP format through the MCAD bridge. Components that are not contributing to the heat transfer, have been removed from the geometry. The model consists of the four major components:

3D CAD Geometry




Figure 1. 3D geometry of the model

3D geometry is created by importing a CAD model in STEP format through the MCAD bridge (Figure 1). The PCB has been simplified to a bulk geometry where the copper layers and vias have been taken into consideration by assigning anisotropic material properties to the PCBs domains.

Origin has been placed so that [0,0,0] is in the lower left corner of the PCB.

Unit in file: [mm]

Domains of power loss distribution

There are several sources for power loss. The power loss for each of them, at certain module total powers, are given in *Appendix 1 - Power Loss Distribution*




Figure 2: Power loss setting: (a) list of heat sources, and (b) heat sources distribution over the model

Domains of material data

There are several material domains. The heat conductivity for each of them is given either as isotropic, or anisotropic values in x-,y-, and z-direction (x,y,z) per the following list.




Figure 3. Domains of material data

Note. The given heat conductivities are only intended to model the temperature distribution of the module in this application. The values should not be treated as physically true or transferable to other applications.

Monitor points

The model comes with predefined monitor points based on the product's thermal report. These monitor points are shown in Figure 4.




Figure 4. Monitor points in the model.

Model Calibration

The model has been calibrated to give temperatures as similar as possible compared to the water-cooling thermal test of this product in a case of 53Vin, 12Vout, and 800W. Therefore, only conduction heat transfer is considered in this calculation. Temperatures of the application board is set to 65[°C] and the baseplate to 100[°C].

Flotherm simulation temperatures are within ± 5 [C] compared to the measured values (see Figure 5).




Figure 5: Model calibration result: MEAS – Thermal test results, FLTM – Flotherm simulation results.



Model Usage

Import the *.pdml file into the desired project.

Adjust the dissipated power by altering the thermal sources per Figure 2, according to Appendix 1 - Power Loss Distribution. Default settings are for 53Vin, 12Vout, 800W.

If the model is rotated, make sure that the orientation of the orthotropic materials properties is preserved (also rotated).

Do not change the order of power sources and geometry objects, as this can change the power and material settings.

The module temperatures can be monitored in predefined monitor points.

Additional Information

Model has been constructed with SI units.

Reference

3/10265-BMR4920300/864

19010-BMR4920300.pdml

Disclaimer

The model and model documentation described herein are provided for the sole purpose of facilitating thermal modeling of a structure where the referenced product is included. It should not and cannot be interpreted neither as a detailed description of the product itself, nor as a statement of the product's performance.

The model has been constructed on a best effort basis, but we cannot accept liability for any discrepancy between model predictions and actual values.

Revision history

A 2021-11-04 New Document



Appendix 1 - Power Loss Distribution

Power loss distribution examples for BMR492 0300/864.

Condition: 52V_{in}, 12V_{out}, 800W_{out} (default setting in the model).

Domain	Number of domains/ boundaries	Domain volume [mm ³]	per domain [W]	per volume [mW/mm ³]	Subtotal power loss [W]
Prim-Mos	4		1.33		5.32
Sec-Mos	8		0.61		4.88
M300-F		1620		1.30	2.10
M300-W		701		10.99	7.70
M400-F		694		0.79	0.55
M400-W		533		5.44	2.90
SN	2		0.12		0.24
Driv-p	2		0.13		0.26
Driv-s	2		0.2		0.40
Aux	1		0.73		0.73
In-Ind	1		0.85		0.85
pcb	2		1		2.00
				Total (W)	27.9



Power loss distribution examples for BMR492 2300/001.

Condition: 53V_{in}, 10.4V_{out}, 700W_{out}.

Domain	Number of domains/ boundaries	Domain volume [mm ³]	per domain [W]	per volume [mW/mm ³]	Subtotal power loss [W]
Prim-Mos	4		1.3		5.20
Sec-Mos	8		0.69		5.52
M300-F		1620		1.02	1.65
M300-W		701		11.13	7.80
M400-F		694		0.94	0.65
M400-W		533		6.11	3.26
SN	2		0.12		0.24
Driv-p	2		0.13		0.26
Driv-s	2		0.2		0.40
Aux	1		0.73		0.73
In-Ind	1		0.85		0.85
pcb	2		0.65		1.30
				Total (W)	27.9